



Product guide

M812 Felt Board with Pocket, M813 Mirror Board with Pocket, M828 Carpet Board, M829 Storage Board

IMPORTANT

Save these instructions for reference.

Recommended use

Accessory Boards offer configurable features to support regulation and provide storage in some Community Playthings Calm Corner items.

⚠ WARNING

▲ This product is intended for use by children of immature judgement and therefore adult supervision is required at all times.

Mounting

Accessory Boards may be added to the FlexiDen Island Arch, FlexiDen Arch and the Nest Nook, and slot in to either side, with built-in hardware.



Maintenance

Periodically inspect for cracks, breaks, loose parts, missing parts, and/or malfunctions. Remove the product from service if any condition develops that might make operation unsafe.

Cleaning

Wipe wood with a damp cloth and mild detergent. Dry immediately. Leaving water or cleaning agent on the surface may damage the finish. When cleaning plastic surfaces, do not use harsh detergents or cleansers as these may scratch or mar the surface. Non-toxic household plastic cleaners should work well.

The carpet is attached with hook-and-loop fasteners and may be removed for cleaning or replacement. We recommend steam cleaning the carpet. Do not soak carpet to remove stains, dirt or other grime. Do not rinse under the tap or use excessive water. Carpet stains and spots should be attended to as soon as they occur. Liquid stains like ink can be removed by using absorbent cloth. Solid stains should be taken out with a spoon or the end of a knife. To prevent the stain from spreading, don't rub it; instead, remove the stain by firmly dabbing it repeatedly with an absorbent cloth, starting from the edges and moving to the centre.

Construction

Accessory Boards are constructed from hardwood plywood, durable plastic, hook-and-loop velour, carpet and zinc-plated hardware.

User modifications

We cannot be responsible for modifications made by customers to our products in the field without our supervision, testing, or evaluation.

Ordering parts


To order replacement parts, contact customer service with a description of the part(s) needed and the ID code from the product. **Use only replacement parts supplied by Community Playthings. If your shipment is incomplete, please call customer service. All the packaging from this product is recyclable (cardboard and LDPE). Please recycle in accordance with local guidelines.**



M812



M813



M828



M829